



# CHANGE YOUR SIGNIA WAXGUARD FILTER



Better Hearing. Better Life.

**1 TAKE ONE**  
replacement stick.



Each replacement stick has a new filter on the end.

**2 REMOVE**  
the used filter.



First, remove the rubber tip. Use the black end of the replacement stick to pull out the old filter.

**3 INSERT**  
the new filter.



Insert the white end (new filter) of the replacement stick into the receiver end.

**4 DONE!**  
You're all set.



Discard the replacement stick in the trash. Enjoy clear sound!



**HELPFUL TIPS:**



Replace the filter when you notice reduced sound quality.



Change filters regularly for the best sound and performance.



Always use a new stick for each filter.



**Absolute  
Hearing Solutions**

750 Cross Pointe Road Suite F  
Gahanna, Ohio 43230  
614-452-4280  
www.absolutehearingsolutions.com  
absolutehearing@att.net